ELPO — OOD
EA — COB
ELCPO — XO
ENG — CO
EDMC

1 Feb 01

Ground Strap for Temp Sensor Htr #42 is broken/disconnected. (Located on fwd port side of Conn on post)

ELPO — OOD
EA — XO
ELCPO — CO
ENG
EDMC

1 FEB 01

The IM-247 Frisker in Engineroom Forward cannot be used due to a broken cable. The part is in RL-Div's ESL and the job will be walked through

CRA — OOD
ENG — EOOW
XO — CO

2/2/01 0515 JSN

Gyro Repeater on Bridge is not working. FAULT IN IDU-1

NavLCPO — XO
NAV — CO
OOD

2/9/01 0810

AVSDU Display in Control will not display anything (Screen completely dark.

STLPO — OOD
Sonar Off. — XO
CSO — CO
COB — COB
2/9/01

#1 Scope Visual Bearing Error is approximately .4 degrees east. Previous to EPAC it was typically 0.

FTLPO — NAV KS
CSO — ANAV
XO — COB
CO — OOD